



How is SILTSHIELD Installed?

Three Fundamental Methods

1. Perimeter Installation

This method is intended for open field or perimeter applications. Insert SILTSHIELD into a six inch deep trench, backfill and compact.

2. Basic Installation

This method is intended for locations with existing curbing. SILTSHIELD is placed against the rear of the curb six inches deep then backfilled and compacted.

(The compacted backfill must be at least at same height as the curbing)

3. New Curbing Installation

This method is suggested for those locations where advance planning affords the opportunity to save time and labor using our Curb Claws. Curb Claws secure SILTSHIELD in place until curbing is backfilled.

(Refer to our Curb Claw Installation sheet)

Note:

Insert bracing stakes/posts at 5 foot intervals

